



Pull back plastic trim and
place adhesive underneath.

Apply along entire height of window.
Repeat on passenger side.