

A technical diagram showing a cross-section of a car's window frame. A grey plastic trim piece is being pulled back from the window frame. A dark grey adhesive strip is shown being applied to the inner surface of the window frame. Three vertical arrows indicate the direction of the trim being pulled back: one at the top pointing up, one in the middle pointing down, and one at the bottom pointing down. A line from the text points to the adhesive strip.

Pull back plastic trim and  
place adhesive underneath.

Apply along entire height of window.  
Repeat on passenger side.